



**How to install our Paddle Shifters on:**

**2012-2015 Chevrolet Camaro / Chevrolet SS Sedan**

**Installation Instructions:**

1 - With the provided small Allen screw, you need to push out the Pin that is holding the existing plastic Paddles. Please make sure you push the pin from the bottom upward

( The threaded side of the holding pin that is on the top needs to come out first )

2 - After you remove the holding pin, you need to remove the existing plastic paddles slowly making sure the spring doesn't fly away !

3 - Now you can place your new Paddles inside the housing, making sure the spring is held exactly as it was before. Once placed correctly, you simply insert the holding pin ( Non threaded side first ). Push it all the way in until you cant see it.

4 - Repeat the same process above on the other side and you're all set !

Any questions, feel free to contact one of our representatives for further assistance

**Tel: 201 708 7017 - Email: [sales@vitesse-motorsports.com](mailto:sales@vitesse-motorsports.com)**